

## INSERT WEAR GUIDE

Worn tips can diminish your scaling efficiency.
Check your inserts every week to maintain optimal performance.

How the best perform



## HOW TO USE YOUR WEAR GUIDE

- 1. Locate the diagram of the insert to be measured (use color as guide).
- 2. Position point A to point B as shown and/or align the curvature of the tip (circled) to match the guide.
- 3. Rotate insert until tip is flat against the card.
- 4. Evaluate tip condition, comparing length to red/blue bars.

**Reorder** tips when 25% efficiency loss (blue bar) **Discard** tip when 50% efficiency loss (red bar)



## Learn more at Hu-Friedy.com/Inserts

To reorder inserts call **1-800-Hu-Friedy** or your authorized Hu-Friedy dealer.

©2015 Hu-Friedy Mfg. Co., LLC. All rights reserved. HF-466/1015



